### **Saver SM Maintenance Schedule**

# **Every 3 Loads**

Clean both air lint filters. Clean button trap basket.

## **Each Day**

Drain moisture from airline filter \*

#### Weekly

Take apart foam air lint filter and wash out embedded lint, allow to air dry over night, re-assemble and put back in place

Clean separator.

Clean Dual Fan Refrigeration Coils.

### Every 20 Loads

Change Powder.

Clean Spin Filter # 1. Run Clean Filter # 1 program # \_\_20\_\_\_\*

# **Every 200 Loads**

Manually drain the Kleen Rite Housing on Filter # 2 overnight and change the Cartridges \*

#### Quarterly

Check drive belt tension, Mounting and bearing housing bolts, Adjust and tighten as necessarily.

Clean separators manually remove glass, wipe out after draining. Clean Inverter.

## Semi-Annual

Drain Base Tanks and Clean out

### Annually

Clean Evaporator Coil

<sup>\*</sup> The computer can be programmed to have a message appear on the screen Informing the operator that it is time to run these maintenance programs.